QUICK GUIDE · SONOS


Play Tonada on Sonos

Add Tonada to the Sonos app once and sign in. It takes about a minute, and you need no extra hardware.

BEFORE YOU START


- **A Sonos system** — Set up in the Sonos app
- **The Sonos app** — On your phone, tablet or computer
- **Your Tonada login** — Email and password

1 STEP 1 OF 7 Open Your Services




In the Sonos app, go to **Home**, find **Your Services** and tap **+**.

2 STEP 2 OF 7 Search for Tonada




Type “Tonada” in the search field. Select **Tonada** from the results.

3 STEP 3 OF 7 Add Tonada to Sonos



On the Tonada page, tap **Add to Sonos**.


4 STEP 4 OF 7 Sign in to Tonada



Enter your Tonada email and password. Tap **Sign in**, then return to the Sonos app.

5 STEP 5 OF 7


Finish the setup



Sonos shows **Setup Complete**. Tap **Done**. The check box is optional.

6 STEP 6 OF 7


Open Tonada



Tonada now appears under **Your Services**. Tap it.

7 STEP 7 OF 7

Pick a vibe and press play



Tap **Locations**. Choose your location and your zone. Pick a vibe and press play.

That's it. Tonada is now live in Sonos.

TROUBLESHOOTING

Quick fixes

"Invalid email or password"?

Use the same email and password as in the Tonada app.

Don't see your location or zone?

Sign in with a Tonada account that has access to that location.

A spoken notice in place of music?

Your Tonada plan is not active. Check the payment method in the Tonada app.

Need a hand? We're happy to help. hello@tonada.com